

Programming Corvette Radios
To receive XM Satellite Radio

Must be programmed as Uplander-U body

1. Using the Tech2 diagnostic tool, plug tool into OBDII connector and turn on the power for the Tech2
2. Hit the enter key, then select diagnostics
3. Select year of vehicle
4. Select LD Trk, MPV, Incomplete data
5. Select Chevrolet
6. Select U body
7. Select Body and Accessories
8. Select Entertainment
9. Select Module setup
10. Select Radio
11. Select Optional Modules
12. Select Continue
13. If the star (*) icon is not next to "Digital Radio Receiver", highlight line, and hit enter. The star icon will appear
14. Hit "save options"
15. Recycle ignition switch, and press the "Band" button on the radio until XM is displayed